

1

INSTALLING YOUR TRACKER


The Auto 325 tracker gets its power from the car's OBD port. To get started, simply plug the tracker into the port. This is typically underneath the steering wheel or by the floorboard on the driver's side.



2

DOWNLOAD THE TRACKING APP

Download the mobile app from the App Store or Play Store by searching for 'logistimatics'.



3

LOGIN WITH EMAIL & PASSWORD

Login to the app with your email address and the password you used when you purchased your tracker



The tracker can be plugged directly into the OBD port or an OBD extension cable can be used. If the extension cable is used, it can be routed to a less conspicuous location.

Tracker Placement



To be notified if your tracker enters or exits an area, create a geofence. In the mobile app, click Geofences > New Geofence. Give your new geofence a name, address and size.

Setting up alerts



The default tracking mode updates every 30 seconds when the vehicle is powered on and moving.

Reporting Modes



You can add additional users via the tracking website gps.logistimatics.com
Go to Account > Settings > Add Users

Add additional Users

Setting up live audio for your tracker

1 Make sure tracker is on

Before you can use live audio, the vehicle will need to have power to the device. First make sure your tracker is plugged into the car's OBD port and reporting before calling the tracker.

2 Call your tracker's phone number

To start listening, simply call your tracker's phone number. You can get the phone number from the mobile app by clicking the INFO tab. To send a text to your tracker to have it call you, this can be found in the COMMANDS tab.

3 Have tracker call you

To start listening, simply go to the mobile app and click Commands > New to send a new command > Have tracker call you.

You can also text your tracker this command:
111111MON

4 The tracker will call your cellphone

The tracker will call you to begin audio monitoring on the tracker.